




# 1.4 Mouse handling

The mouse options can be accessed under *Help ? Mouse help:*




- L** : select
- M** : pan
- Wheel**: zoom
- R** : orbit
  
- Shift L** : select +/-
- Ctrl L** : orbit
- Alt L** : pan


## Overview:



**Middle mouse button M:** Zoom in and out in screen view.



**Hold down the mouse wheel and move the mouse at the same time:** Screen view is shifted (like pan function).



**Hold down the right mouse button R and move the mouse at the same time:** Screen view is rotated.

If you also hold the `Ctrl` key, you rotate around your own axis.