


1.1.1 Install Lexocad

1.Download setup ? open ? more



3. Open Lexocad via desktop icon or enter Lexocad in Windows search

