



4.1.20 Measure


Distance measurement ?  key

 key: The distance between 2 points can be measured

Example:  key ? select points 1 and 2 ? window opens with distance indication



"Measure" icon:



Basic measurements: distances, radii, angles can be measured

Coordinates: Measurement of global and local coordinates

Active elements: dimensions of active elements can be measured