


4.36 Export

It is possible from lexocad to export different types of files.



To do this, click on "file / export".



In the sub-menu all possible imports are proposed. Among the main ones are :

- Lexocad files with only the elements visible on the screen
- 3D cadwork files
- html files
- BIMteam files
- IFC files
- OBJ file - Wood list
- Metal list
- List of roofing (quantity of tiles)
- Architecture list (surfaces)